

# FAT BIKE

If you are breaking through the surface of the trail and leaving ruts, not getting traction, or slipping in turns, reduce your tire pressure.

## AIR PRESSURE TIPS



**Incorrect**



**Correct**

## Fat Bike Best Practices

- Wide tires only, minimum width 3.7"
- Tire pressure no higher than 8 PSI
- Have enough flotation that when traveling over the snow you don't leave a rut deeper than 2"
- Sufficient traction that you are able to control your bike safely in a straight line
- Do not disturb the wildlife
- Understand changing conditions
- Usually dry snow with no moisture or wet snow in above freezing temps, 1-4 psi is recommended
- If you are riding a trail that is hard packed with temps consistently below freezing and you are not breaking the surface, 6-8 psi is recommended depending on rider weight
- Be prepared if you have to stay out longer than planned
- Let people know where you are going if riding alone



[www.kamba.org](http://www.kamba.org)

 [kenoshacountyparks](https://www.facebook.com/kenoshacountyparks)  
[kenoshacounty.org](http://kenoshacounty.org)

